


OLLI Audio / Visual Equipment

Classroom B

1. Turn on the **Main Power** (labeled with the green dot)
2. Power on your projector of choice (remotes are on the laptop podium)
 - a. **Smart Board Projector:** white remote, blue power button
 - b. **Ceiling Projector:** white remote, red power button
3. Power on additional equipment as needed:
 - a. Laptop
 - b. Microphones
 - c. DVD / VCR



Please leave the equipment on for the next class!

-- Thank You!

OVER →

Additional Operations

Mixer Volume:

Master Volume Control controls the volume level for all devices (if you have issues, please ask the office staff for assistance).

Microphones:

- Multiple microphones can be used simultaneously
- We strongly encourage use of the headset mic to help our hearing impaired students
- Do NOT change the antenna settings on the unit or the box (if you have issues, ask the office staff for assistance)

Laptop (HDMI 1):

1. Enter the user name that is on the label on the computer
2. Enter the password that is on the label on the computer

Bluray Player (HDMI2):



Ceiling Projector Remote



Smart Board Remote



BluRay Remote

Hearing Assist Devices are available in the Main Office.

Office Staff are available to help! Please bother us!